



Use a screwdriver with a handle, like this one.



C key.



C# Key.

The keys are not the same. They are 'handed'.

This picture shows the notches on the C# key. The C key has them as well.

The notches cannot be seen when the keys are on the saddle.

The fingers on the saddle must point to the holes.

The saddle screw must be fully tightened.

The keys should drop snugly onto the saddle with their pads over the holes and their notched sides next to each other.

Firm pressure on the saddle end of each key will make it click into position.